

## Quick Start Guide for FastLynx 3.3

### Two Computers Running Windows 95 or Higher

*Note: If using the USB bridge cable, it is imperative that you install the software **before** plugging the cable into your computer. Also, you must be running Windows 98 or higher on **both** computers in order to use the USB bridge cable.*

1. Insert the floppy disk entitled "FastLynx 3.3" into the floppy drive.
2. Go to start/run and type a:fx33 (where a is the letter of the floppy drive) and hit <enter>.
3. After the program verifies the integrity of the file (this will take a moment), click on the button that says "Install."
4. If prompted to create a new directory for FastLynx, choose "Yes."
5. Once you have read and agreed to the license agreement, click "I Agree."
6. Check the desired boxes and click "OK."

*Windows XP Users: At this point you may get a Windows dialogue box telling you that the software has not passed Windows Logo Testing. Choose "Continue Anyway" to continue the installation.*

7. Repeat steps 1-6 on the second computer.
8. Plug the cable (USB bridge, parallel or serial) into each computer.
9. On the right side of the split screen, set one computer to "Listen as Server." Set the other computer to "Connect as Client."
10. On the computer set as the client, the left pane displays the computer's local content. The right pane displays the contents of the server. File transfers can now be made in either direction by selecting the file you wish to move or copy and choosing in the left hand corner "move" or "copy."

### DOS to Windows\* Transfers

*Note: For this type of transfer, you may use either the parallel or the serial cable. The USB bridge cable will not work.*

1. Insert the floppy disk entitled "FastLynx 3.3" into the floppy drive of the computer running Windows.
2. Go to start/run and type a:fx33 (where a is the letter of the floppy drive) and hit <enter>.
3. After the program verifies the integrity of the file (this will take a moment), click on the button that says "Install."
4. If prompted to create a new directory for FastLynx, choose "Yes."
5. Once you have read and agreed to the license agreement, click "I Agree."
6. Check the desired boxes and click "OK."
7. Go to the folder FastLynx has been installed to (i.e., c:\Program Files\FastLynx) and find the file entitled "sl.exe."
8. Copy this file onto a floppy disk.
9. Take the floppy to the other machine. Type a:sl.exe (where a is the letter of the floppy drive).
10. Plug the cable (parallel or serial) into each computer.
11. Set the Windows computer to "Connect as Client."
12. On the Windows computer, the left pane displays the computer's local content. The right pane displays the contents of the server. File transfers can now be made in either direction by selecting the file you wish to move or copy and choosing in the left hand corner "move" or "copy."

\* Windows being a computer running Windows 95 or higher.